

Part Number	Description	QTY	UM	COND
064-1005-14	COMPUTER, VHF COMM	1	EA	SV
066-1019-01	DME	1	EA	AR
066-1149-48	NAV/ILS RECEIVER	3	EA	AR
066-50003-0101	TRAFFIC DISPLAY	2	EA	AR
071-50001-8102	TCAS ANTENNA	2	EA	SV
0856CC-10	PITOT TUBE	2	EA	SV
0856CC-11	PITOT TUBE	2	EA	SV
0856CC-12	PITOT TUBE	2	EA	SV
10-3200-3	GATE S/O VALVE	1	EA	AR
10-383900-16	EXCITER	1	EA	AR
102LA2AG	SENSOR	1	EA	SV
1052-3	SEAT OBSERVER	1	EA	AR
1075-1	SEAT OBSERVER	1	EA	AR
109300-16	PNEU DRIVE	2	EA	AR
109395-1	S/O CONT. VALVE ASSY	2	EA	AR
1171-084	SWITCH	1	EA	SV
109395-2	S/O CONT. VALVE ASSY	2	EA	AR
1176T100-3	ROTARY ACTUATOR	2	EA	AR
121628-4	METERING VALVE	1	EA	AR
126344-17	PNEU DRIVE ACTUATOR	2	EA	AR
126344-19-1	PNEU DRIVE ACTUATOR	2	EA	AR
126344-25	PNEU DRIVE ACTUATOR	2	EA	AR
126366-19	PNEU DRIVE ACTUATOR	2	EA	AR
126366-22	PNEU DRIVE ACTUATOR	3	EA	AR
126748-1-1	MOTOR	1	EA	AR
126748-2-1	MOTOR	1	EA	AR
126748-3	MOTOR	1	EA	AR
1387T100-11	ROTARY ACTUATOR	1	EA	AR
149155-01-01	INDICATOR, ALT DIR	1	EA	AR
149155-01-02	ADI	1	EA	AR
190190-501	MODULE HYD ADP AUTO	1	EA	AR
1903896-1	SERVO AUTOTHROTTLE	2	EA	AR
1903925-1	CADC	1	EA	AR
1903925-4	COMPUTER	2	EA	AR
1912-02	ANTENNA, LIGHTNING	5	EA	AR
194110-1	HEAT EXCHANGER	1	EA	OH

Part Number	Description	QTY	UM	COND
1U1171-5	ACTUATOR	2	EA	AR
1U1192-8	ACTUATOR W/G DOOR	1	EA	AR
1U1193-7	ACTUATOR ASSY	1	EA	AR
1U1198-8	ACTUATOR ASSY	1	EA	AR
1U1204-4	NOSE GEAR LOCK	2	EA	AR
1U1261-3	POSITION VALVE	1	EA	AR
200-007-005	INDICATOR	5	EA	AR
200-007-006	INDICATOR	5	EA	AR
2041232-1101	RADAR INDICATOR	2	EA	AR
20501-3	LIGHTNING PROTECTOR	4	EA	AR
2070409-0101	WEATHER RADAR	2	EA	AR
2070410-0101	RADAR TRANS RECEIVER	2	EA	AR
218386-3	SCAVENGE PUMP	4	EA	AR
	218387 APU FUEL PUMP	1	EA	AR
21B73-2A	GENERATOR CONTROL	2	EA	AR
21B77-1-C	GENERATOR CONTROL	2	EA	AR
21B77-2-A	GENERATOR CONTROL	2	EA	AR
21B77-2-B	GENERATOR CONTROL	4	EA	AR
21SN41-13	PRESS SWITCH	3	EA	AR
2590622-901	ROLL COMPUTER	2	EA	AR
2590622-933	PITCH COMPUTER	2	EA	AR
2594661-704	RMI	2	EA	SV
2601902-6	BRAKE ASSY	1	EA	SV
2601902-60	BRAKE ASSY	10	EA	AR
2603561-16	WHEEL ASSY	4	EA	AR
2605155-1	BRAKE	5	EA	AR
	2607081 WHEEL ASSY	2	EA	AR
28000-1	REGULATOR	5	EA	AR
28310-02	MASK, OXYGEN	1	EA	FN
29310-4	O/B FLI SPO	5	EA	AR
30-0910-3	ANTI COLLISION LIGHT	2	EA	AR
3170120-3	I/B AILERON CONTROL	3	EA	AR
	31701304 O/B AILERON CONT. PA	3	EA	AR
32-2963-010	CONTROL VALVE	1	EA	AR
350880-6	HYD. PUMP	2	EA	AR
350880-7	HYD. PUMP	10	EA	AR

Part Number	Description	QTY	UM	COND
358-1030V	MASK, OXYGEN	2	EA	AR
3600-13	DRAIN VALVE	1	EA	FN
3757202-1	YAW DAMPER COMPUTER	3	EA	AR
378201-15	PUMP, FUEL	2	EA	SV
398310-3-1	BUTTERFLY VALVE	4	EA	AR
398310-5-1	BUTTERFLY VALVE	2	EA	OH
40-805	TRANSDUCER	10	EA	AR
40176-7	BATTERY	2	EA	AR
4026270-908	ROLLOUT UNIT, LANDING	2	EA	AR
40885-2	CONTROL VALVE	2	EA	AR
42-319-3	AUTO BRAKE CONT UNIT	5	EA	AR
463001-8170-0413	INU	2	EA	SV
	472622 FIRE &OVHT MODULE	1	EA	SV
4812-70	LAV. PUMP	2	EA	AR
50076-0000-02	TRIM UNIT	1	EA	SV
51224-001	ELEMENT	1	EA	SV
51224-001	ELEMENT	1	EA	AR
	520750 INDICATOR, OIL TEMP	1	EA	SV
522-1836-00	RECEIVER, ADF	1	EA	OH
522-1837-000	ANTENNA ADF	3	EA	AR
522-2996-011	RECEIVER, MARKER BEA	1	EA	AR
	56193 HYD. PUMP	1	EA	AR
57186-01	HYD. PUMP	1	EA	AR
	58172 HYD. PUMP	1	EA	AR
59500000-1	D.M.E. INDICATOR	1	EA	AR
59500000-2	D.M.E. INDICATOR	1	EA	AR
60-703103	MOTOR IMPELLER	2	EA	AR
60-72301	MOTOR IMPELLER	2	EA	AR
60-75501	MOTOR IMPELLER	2	EA	AR
60-75502	MOTOR IMP. SUB ASSY	4	EA	AR
60-75503	MOTOR IMP. SUB ASSY	2	EA	AR
60-75504	MOTOR IMP. SUB ASSY	2	EA	AR
600200-18	PNEU ACTUATOR	2	EA	AR
600200-19	PNEU ACTUATOR	4	EA	AR
601300-11	LINEAR ACTUATOR	2	EA	AR
605457-3	FAN, CENTRRFUGAL	2	EA	AR

Part Number	Description	QTY	UM	COND
605457-7	FAN, CENTRRFUGAL	4	EA	AR
607690-2	ELT	4	EA	AR
607690-5	ELT XMTR	2	EA	AR
60B00010-20	CIRCUIT BREAKER	2	EA	AR
60B00050-2	ACTUATOR	1	EA	AR
60B07640-19	COCKPIT GLASS	1	EA	AR
60B07640-2	COCKPIT GLASS	1	EA	AR
60B10028-102	COCKPIT GLASS	1	EA	AR
60B40003-2	INDICATOR, SERVO ALT	1	EA	AR
60B50042-1	LIGHT, EMERGENCY	2	EA	AR
60B80031-8	CONTROL CHANGER	1	EA	AR
60B80032-1	ACTUATOR	1	EA	AR
617154-5	WIND HEAT CONT UNIT	3	EA	AR
622-2224-001	TRANSPONDER	1	EA	AR
622-2588-002	TRANSCEIVER	1	EA	AR
622-2878-001	FLIGHT MODE ANNUN.	1	EA	AR
622-2921-001	DIST MEAS EQPT	1	EA	AR
622-3371-004	TRANSMITTER	1	EA	AR
622-3890-103	RADIO ALTIMETER	1	EA	AR
622-6831-021	VHF/COMM CONT P	1	EA	SV
622-8973-004	ANTENNA	1	EA	SV
64161-233-1	PNUMATIC ALT. IND.	1	EA	SV
65066-06	HYD. PUMP	1	EA	AR
6577-1	VANAXIAL FAN	2	EA	AR
65B01087-52	SPINDLE	2	EA	AR
65B01502-11	ACTUATOR	1	EA	AR
65B01503-16	ACTUATOR	1	EA	AR
65B01502-12	ACTUATOR	1	EA	AR
65B01437-6	SPINDLE	1	EA	AR
65B02250-41	SPOILER	1	EA	AR
65B02310-1	SPOILER	1	EA	AR
65B08027-41	FLAP CARRIAGE ASSY	1	EA	AR
65B10187-52	FLAP CARRIAGE	1	EA	AR
65B10187-55	FLAP CARRIAGE	1	EA	AR
65B46189-17	FIRE PROTECT. PANEL	1	EA	AR
65B47509-26	FIRE DETECTION ASSY.	1	EA	OH

Part Number	Description	QTY	UM	COND
65B47509-26	FIRE DETECTION ASSY.	1	EA	AR
65B47509-57	FIRE DETECTION ASSY.	1	EA	AR
65B47509-58	FIRE DET. SYSTEM	1	EA	AR
65B82585-4	NOSE GEAR ACTUATOR	1	EA	AR
65B82703-51	CONTROL PANEL	1	EA	OH
65B82703-51	CONTROL PANEL	1	EA	AR
65B94200-201	NOSE COWL	2	EA	AR
65B94241-39	CENTER COWL	2	EA	AR
65B94280-186	REAR COWL RH	2	EA	AR
67-2985-002	AIR S/O VALVE	2	EA	AR
67-3139-003	ANTI ICE VALVE	1	EA	AR
673U0032-37	CENTER COWL LH	1	EA	AR
69-37338-35	PANEL	1	EA	SV
69-37344-22	PANEL	1	EA	SV
705117L	CSD	1	EA	OH
717998-4	CHECK VALVE	3	EA	AR
719201-11	VALVE, OUT FLOW	1	EA	AR
719201-11	VALVE, OUT FLOW	1	EA	OH
719218-8	VALVE	2	EA	AR
719223-4	TURBINE BYPASS VALVE	4	EA	AR
719224-3	ZONE TRIM VALVE	4	EA	AR
719226-7	WATER SEPARATOR	1	EA	AR
719235-9	HEAT EXCHANGER	3	EA	OHC
719238-11	AIR CYCLE MACHINE	1	EA	OH
719238-12	AIR CYCLE MACHINE	1	EA	OH
719238-9	AIR CYCLE MACHINE	1	EA	OH
719239-1	DIFFUSER INLET	3	EA	AR
724282-1	OUTFLOW ACTUATOR	3	EA	AR
726574-7	VALVE, STARTER S/O	1	EA	OH
728814-2	CLUSTER GEAR	3	EA	SV
728843-1	RING GEAR CARRIER	1	EA	SV
738143-6	TURBINE ROTOR	1	EA	SV
739148-7	CONTAINMENT HOUSING	1	EA	SV
739168-3	CLUTCH PAWLS	3	EA	SV
732-16830-01	AUTO SPEED BRAKE	1	EA	AR
732-16870-02	AIR INLET SYSTEM	1	EA	AR

Part Number	Description	QTY	UM	COND
738362-22	PYLON VALVE	1	EA	AR
740179-3	STARTER	1	EA	AR
742686-5	RAM AIR ACTUATOR	1	EA	AR
742868-2	RAM AIR ACTUATOR	2	EA	AR
742868-5	RAM AIR ACTUATOR	4	EA	AR
743-0238-001	VIDEO CASSETTE PLAYER	4	EA	AR
743841-5	PACK TEMP. CONT.	4	EA	AR
747-5100-5-0	PDU	6	EA	AR
747-5700-3-0	ACTUATOR	4	EA	AR
750399-3	WATER SEPARATOR	5	EA	AR
7514081-901	TCAS ANTENNA	3	EA	AR
758974-3	EXHAUST DEFLECTOR	1	EA	SV
764476-3	CONTROL VALVE	4	EA	AR
767460-2	FLOW CONT VALVE	4	EA	AR
772-5005-001	FLIGHT DIRECTION IND	2	EA	AR
777-1328-001	COUPLER ANTENNA	1	EA	AR
777-1328-001	COUPLER ANTENNA	1	EA	SV
777-1329-001	CONTROL ANTENNA COUP	4	EA	AR
777-1492-001	RECEIVER	1	EA	AR
777-1492-003	ADF RECEIVER	2	EA	AR
777-1826-004	CIWS COMPUTER	4	EA	AR
7883460-031	CAROUSEL DISP UNIT	3	EA	AR
7883470-011	MODE SEL. UNIT	3	EA	AR
7891390-011	CONTROL DISPLAY UNIT	3	EA	AR
793T100-7	ALT FLI DRIVE UNIT	4	EA	AR
7G110-3	SWITCH, PRESSURE	1	EA	AR
800801-1	PNEU CONTROL UNIT	2	EA	AR
811369-613	CAPTAIN SEAT	2	EA	AR
811370-621	FIRST OFFICER SEAT	2	EA	AR
811372-321	FLIGHT ENGINEER SEAT	2	EA	AR
822-0314-101	SATELLITE DATA UNIT	1	EA	AR
822-0731-001	VHF TRANSCEIVER	1	EA	AR
822-0732-001	TRANS RECEIVER	1	EA	AR
822-0761-001	TRANSCIEVER	1	EA	OH
8901-224	SENSOR	1	EA	AR
8DJ161LWP	INDICATOR, EPR	1	EA	AR

Part Number	Description	QTY	UM	COND
8DJ163LXF4	INDICATOR, EGT	1	EA	SV
.9032-4-2	CHECK VALVE	1	EA	OHC
.9032-4-1	CHECK VALVE	1	EA	OHC
.9032-4-3	CHECK VALVE	2	EA	OHC
93-A100-31	COCKPIT VOICE RECORDER	1	EA	AR
93600-5019	ELEV. CONT. PACKAGE	1	EA	AR
93600-5031	ELEV. CONT. PACKAGE	1	EA	AR
93600-5035	ELEV. CONT. PACKAGE	1	EA	AR
93600-5037	ELEV. CONT. PACKAGE	1	EA	AR
93600-5047	ELEV. CONT. PACKAGE	1	EA	AR
93600-9043	ELEV. CONT. PACKAGE	1	EA	AR
93600-9051	ELEV. CONT. PACKAGE	1	EA	AR
93700-5005	PCU, ELEVATOR O/B	1	EA	AR
93700-5009	POWER CONT. UNIT	1	EA	AR
93A152-20	CVR CONTROL PANEL	1	EA	SV
944321-15	RELAY	1	EA	AR
965-0648-007	G.P.W. COMPUTER	1	EA	SV
975-0145-004	SWITCH, THERMAL	1	EA	AR
9807-53	INDICATOR, OIL PRESSURE	1	EA	SV
A100	COCKPIT VOICE RECORDER	1	EA	AR
A43217-10-013	INDICATOR, MACH AIR	1	EA	AR
D2063-11	PDU	1	EA	AR
D2067-3	ROTARY ACTUATOR	4	EA	AR
D2070-1	ACTUATOR	2	EA	AR
D2070-2	ACTAUTOR	1	EA	AR
DL1020M159-2	ACTUATOR LAT TRIM	2	EA	AR
DL1020M186-5	ACUTATOR	1	EA	AR
DL1326M119-2	ACTUATOR O.B	2	EA	AR
DL2033M4-3	ACTUATOR	1	EA	AR
DL2033M4-2	ACTUATOR	1	EA	AR
DSF508-17	INDICATOR, OIL QTY	1	EA	AR
ED747201-2	XMTR	2	EA	AR
G7406-05	CONTROL PANEL	1	EA	AR
MA11A11-94	ELECT MOTOR	3	EA	AR
MI-585161	RECEIVER/TRANS.	1	EA	AR
MI-585229	TMG CONTROL	1	EA	AR

Part Number	Description	QTY	UM	COND
MI592087	RADAR ANTENNA	1	EA	AR
NA135	SECAL	2	EA	AR
NP-103801-114	COCKPIT GLASS	1	EA	AR
R1419M14	ACTUATOR	1	EA	AR
RD-AX7351	TAPE REPRODUCER	2	EA	SV
RG24320C	ROTARY PUMP	1	EA	AR
RR24640	PUMP, FUEL APU	1	EA	AR
S65-5366-7L	LBAND ANTENNA	3	EA	AR
XW21372-12A	WIPER MOTOR	2	EA	AR
XW21372-23	WIPER MOTOR	2	EA	AR
XW21372-24	MOTOR CONVERTER	2	EA	AR
XW22913-7	WIPER ARM	2	EA	AR
XW22913-8	WIPER ASSY R/H	2	EA	AR